

**INSTRUCTIONS FOR THE FOLLOWING FIXTURES:**

ORDER#	MODEL#
R39009	RENO-NX-HL-HB

Note: The following instructions must be completed prior to hardwiring the box  
 Note :Les instructions suivantes doivent être accomplies avant de câbler la boîte.

**1** **②** Prior to installation, Select the appropriate entry hole and introduce the power supply wire. fasten the electrical box body with screws. Connect supply wire into the quick connectors. black to black(L), white to white(N), and green to green

**①** Unscrew the box cover.

**③** Screw the box cover.

**2**

Connect flexible wire connector or link connector or (Notched End) to the box. Raccordez le connecteur de fil flexible ou connecteur (*Spaltende*) à la boîte.

**3**

Connect the other side of the flexible wire connector or link connector to the fixture. Raccordez l'autre côté du connecteur de fil flexible ou connecteur au luminaire.