

Date:	Project Name:
Type:	Part Number:

# RENO-V2A-MW-MCCT INSTALLATION GUIDE

## INSTRUCTIONS FOR THE FOLLOWING FIXTURES

Order	Model
R32007	RENO-V2A-MW-MCCT

### SAFETY:

This fixture must be wired in accordance with the National Electric Code and applicable local codes or ordinance. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician. To insure personal safety, proper grounding is required (connect green fixture wire to supply ground).

### IMPORTANT:

Read all instructions carefully before attempting installation.

### INSTALLATION STEP:

1. According to the requirements, choose the color temperature and power you need
2. Turn off the power.
3. Use screws(AA) to lock the mounting plate(BB) on the box.
4. Connect the ground wire on the back of the the mounting plate(BB) and the black and white wire on the back of the product with the screw cap(CC), connect to the corresponding line in the J-Box.
5. Align the round hole on the side of the lamp base with the round hole on the side of the mounting plate, and use DD screws to lock them respectively.
6. Turn on the power and check whether the lamps are working normally.

