


INSTRUCTIONS FOR THE FOLLOWING FIXTURES:

ORDER#	MODEL#
R31321	RENO-THL30W-3CCT-WH
R31322	RENO-THL30W-3CCT-BK

1. The adapter polarity must match the tracks polarity: L-L, N-N, E-E.
2. Push the adapter upwards ① and rotate it to the right ②, install the adapter correctly into the tracks.



1. First, install adapter #1 (see the diagram above for installation instructions). Adapter #1 can only rotate 355° ; it is used to connect the line voltage AC120V.
2. Then rotate adapter #2. It is empty and has no wiring; It can rotate 720° ; It is only used to help secure the fixture.

