

# INSTALLATION INSTRUCTION Neon Strip Top Bend

### Preparation








#### Important

Please take the time to read this installation guide before you install the product. The guide contains important information regarding installation and operation. It must be installed in a proper way.

### Safety & Warnings

- 1. Install in accordance with national and local electrical code regulations.
- 2. This product must be installed and serviced by a qualified, licensed electrician.
- 3. Before installation, maintenance or cleaning, always switch off or disconnect the power first. Before powering on, make sure the wiring is correct.
- 4. Do not connect directly to the main power, the product is connected to SELV LED driver.
- 5. Adopt suitable power supply with power is 20% higher than the max. power of luminary, to ensure long time performance of power supply.
- 6. Please adopt a suitable waterproof rating product, according to actual specific scene.
- 7. Do not install the product in an environment over ambient temperature range ( $-20^{\circ}$  ~ $45^{\circ}$ C).
- 8. Do not exceed maximum run length for the product. Over long length will lead to problem of overload or uneven brightness.
- 9. Avoid scrape, twist and irregular bend during installation, which might cause non repairable status for the luminary, avoid pull hard and fast.
- 10. Minimum bending diameter definition is 200mm[7.87in], too small bending diameter will break the luminary.
- 11. Should two or more people work, make sure somebody help to lift the light during installation.
- 12. Do not modify or disassemble this product beyond instructions or the warranty will be void.


### Bend & Twist








## Cutting






# INSTALLATION INSTRUCTION Neon Strip Top Bend

## End-cap installation guide



## Accessories(optional) installation guide



Note: It's also support surface & recessed mounting by gluing process.