


RKF INSTALLATION INSTRUCTIONS

Retrofit Kit for Flat Panels and Troffers



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE.

RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Fixture must be wired in accordance with the National Electrical Code and all application local codes. Proper grounding is required for safety.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTSALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

MAKE CERTAIN POWER IS OFF BEFORE INSTALLING OR MAINTAINING FIXTURE.

SAFETY INSTRUCTIONS

ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!

WARNING: Risk of fire or electric shock. Suitable for Damp locations.

WARNING: Install Drywall Kit & Panel per local codes.

Suitable for installation in SheetRock/ Pasteboard in both insulated Ceilings and Non-Insulated Ceilings. Not for continuous row mounting.

WARNING: Do not handle energized fixture when hands are wet, when standing on wet or damp surfaces, or in water.

WARNING: Vapor barrier must be suitable for 90°C (194°F).

WARNING: Drywall kit to be independently supported to building struture.


INSTALLATION INSTRUCTIONS

The fixture is suitable only for **INDOOR RECESSED CEILING** application.



Nominal Sheet Rock cut-out opening according to the dimension table. (Fig. 2)

To mount in an insulated or non-insulated-sheet rock ceiling following the steps below.

1. Assemble the four pieces of the **Retrofit Kit** (1x4, 2x2, 2x4) with the screws provided.
2. Support the **Retrofit Kit** (1x4, 2x2, 2x4) to the building structure by Hanger Wires (by others), alternatively screw to Wood Blocking (by others) or black iron (by others).
3. Bend the pre-installed Clips (4) flat to the panel housing.
4. Followed wiring directions on fixture installation instruction sheet to complete electrical splices.
5. Rotate and slide the panel housing as required to fit through the drywall opening as indicated by the directional arrow in figure and place it on the **Retrofit Kit**.



INSTALLATION INSTRUCTIONS CON'T



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.